

CERAMIC REMOVAL TOOL - 3RD GENERATION



3 WAYS TO USE THE CRTX3 TOOL







Three teeth placement:

- When the tile pops-off relatively easily
- When the tile consistently separates intact from the mortar
- When the mortar is soft and powdery

Two teeth placement:

- When the tile is moderately bonded to the mortar and does not separate easily
- When the tile is inconsistently bonded to the mortar and tends to break 50% of the time
- When the mortar is softer and quite crumbly.

One tooth placement:

- When the tile is well bonded to the mortar When
- the tile consistently breaks, and more head pressure is needed to get underneath the tile
- When the mortar is hard and well bonded to the substrate







Replacement Carbide Teeth are sold in packs of three